

# BACNET COMMUNICATION OPTION MANUAL

175W - 750W SINGLE PHASE

# Series LV

# **EMERGENCY LIGHTING CENTRAL INVERTER**

0	

Myers Emergency Power Systems
44 South Commerce Way, Bethlehem, PA 18017
1-800-526-5088 • (610) 868-3500 • Fax: (610) 868-8686
Service: (610) 868-5400
www.myerseps.com

# **Table of Contents**

SECTION 1	2
BACnet Communication Option Board	
SECTION 2	
Description of Operation	2
SECTION 3	
Settings	3
Termination, Baudrate and MAC Address:	3
Factory Defaults:	3
SECTION 4	4
Object Summary	4
Object Summary (con't)	5
SECTION 5	
Protocol Implementation	6
BACnet Standardized Device Profile (Annex L)	6
BACnet Interoperability Building Blocks Supported (Annex K)	6
Segmentation Capability	6
Standard Object Types Supported	6
Data Link Layer Options	6
Device Address Binding	
Networking Options	
Character Sets Supported	

# **BACnet Communication Option Board**

The BACnet Communication Option Board for the Series LV Emergency Lighting Central Inverter has two internal connections, the RS485 communication bus, one external connection, a RS485 output connector, and dip jumpers that setup the baud rate and address. See Figure 1 for locations of the connections.




Figure 1 – Outline of BACnet Communication Board.

## **SECTION 2**

# **Description of Operation**

EBI acts as a simple B-ASC server device. It supports a total of 112 Analog Input (AI), 67 Binary Input (BI) and 3 File (FI) objects. EBI is a full MS/TP master device. The MS/TP MAC address is configurable via seven DIP switches, or optionally using a soft-configured MAC address. EBI supports baud rates of 9600, 19200, 38400, 57600 and 115200. The device requires external network biasing and termination resistors when it is used as an end-of-line device. The MS/TP transceiver is optically isolated and the isolated ground is provided along with + and - EIA-485 terminations.


You may configure the Device Object\_Name and Object\_Identifier and Max\_Master by writing to the appropriate Device object properties.

The built-in objects have a mostly fixed configuration of Object\_Names, engineering units and state text. Al objects have only required properties. Bl objects include fixed Inactive\_Text and Active\_Text property values, as well as all required properties. Objects BI52 through BI67 correspond to input and output contact statuses. The Object\_Name property for these 16 objects are writable. File objects include a writable Archive property. Files are used to access one of three dynamic logs of Alarms, Tests and Events.

## **Settings**

There are two objects, AV1 and AV2 that will allow the software to change the Baudrate and MAC address respectively. If SW2 is in the ON-ON-ON-ON position upon reset or power on the baud rate can be changed by writing to AV-1; Present\_Value through BACnet. The AV1 is not in effect when the right three switches are in any other position than ON. If SW1, switch 8 is in the OFF position upon reset or power on the MAC address can be changed by writing to AV-2; Present\_Value through BACnet. The AV2 is not in effect when switch 8 is in the ON position.

#### Termination, Baudrate and MAC Address:



## **Factory Defaults:**

device.	Object	Name	EBI

device.Object Identifier Device 560000

device.Max\_Master127device.MACaddress01device.Baudrate38400

device.Description

device.Database\_Revision 1

BI52.Object Name Input Contact Status 1

- -

BI58.Object\_Name Input Contact Status 8
BI59.Object\_Name Output Contact Status 1

. . .

BI67.Object Name Output Contact Status 8

# **Object Summary**

objectID	object name	notes
Al1	INPUT VOLTAGE PHASE 1	VAC
Al4	OUTPUT VOLTAGE PHASE 1	VAC
AI7	OUTPUT CURRENT PHASE 1	A AC
AI10	BATTERY VOLTAGE	V
Al11	AMBIENT TEMPERATURE	°C
Al16	SYSTEM DAYS	days (065535)
Al17	UPS RUN TIME	min (065535)
AI18	INPUT CURRENT PHASE 1	A AC
Al21	INPUT FREQUENCY	Hz
Al23	BATTERY TEMPERATURE	°C
Al24	HEATSINK TEMPERATURE	°C
Al25	BATTERY CURRENT	A DC
Al27	UPS EVENTS	no units (065536)
BI3	BATTERY CHARGING STATUS	1=charging
BI4	BATTERY POWER STATUS	1=battery power
BI6	NORMALLY OFF ACTIVE	1=Normally Off Active
BI7	ON UTILITY	1=Utility Powering Load
BI8	SHUTDOWN	1=Shutdown Mode Active
BI9	STANDBY	1=Unit is in Standby
BI10	BATTERY CHARGING BULK	1=Bulk Charging Mode
BI11	BATTERY CHARGING ABSORPTION	1=Absorption Charging Mode
BI12	BATTERY CHARGING FLOAT	1=Float Charging Mode
BI13	MONTHLY TEST	1=Monthly Test Active
BI14	YEARLY TEST	1=Yearly Test Active
BI15	MANUAL TEST	1=Manual Test Active
BI16	LOAD REDUCTION CALIBRATION	1=Load Reduction Calibration Active
BI19	Short Circuit	0=normal 1=alarm
BI20	Overcurrent	0=normal 1=alarm
BI21	Low Voltage Disconnect	0=normal 1=alarm
BI22	Heatsink Over Temp	0=normal 1=alarm
BI23	Input Fuse Failed	0=normal 1=alarm
BI24	Input not Present	0=normal 1=alarm
BI25	Input fuse Failed	0=normal 1=alarm
BI26	Battery Low	0=normal 1=alarm
BI27	RTC Error	0=normal 1=alarm
BI28	High Ambient Temperature	0=normal 1=alarm
BI29	Low Ambient Temperature	0=normal 1=alarm
BI30	High Battery Temperature	0=normal 1=alarm

# **Object Summary (con't)**

objectID	object name	notes
BI31	Low Battery Temperature	0=normal 1=alarm
BI32	Overload	0=normal 1=alarm
BI34	Battery Not Connected	0=normal 1=alarm
BI35	Battery Probe Not Connected	0=normal 1=alarm
BI36	PLL Error	0=normal 1=alarm
BI37	Input Frequency Low	0=normal 1=alarm
BI38	Input Frequency High	0=normal 1=alarm
BI39	Input Voltage Low	0=normal 1=alarm
BI40	Input Voltage High	0=normal 1=alarm
BI41	Output Voltage Low	0=normal 1=alarm
BI42	Output Voltage High	0=normal 1=alarm
BI43	Battery Charger	0=normal 1=alarm
BI46	Load Reduction	0=normal 1=alarm
BI49	Summary Contact	0=normal 1=alarm
BI50	Year Test failed	0=normal 1=alarm
BI51	Month Test Failed	0=normal 1=alarm
BI52*	Input Contact Status 1	0=normal 1=active
BI53*	Input Contact Status 2	0=normal 1=active
BI54*	Input Contact Status 3	0=normal 1=active
BI55*	Input Contact Status 4	0=normal 1=active
BI56*	Input Contact Status 5	0=normal 1=active
BI57*	Input Contact Status 6	0=normal 1=active
BI58*	Input Contact Status 7	0=normal 1=active
BI59*	Input Contact Status 8	0=normal 1=active
BI60*	Output Contact Status 1	0=normal 1=active
BI61*	Output Contact Status 2	0=normal 1=active
BI62*	Output Contact Status 3	0=normal 1=active
BI63*	Output Contact Status 4	0=normal 1=active
BI64*	Output Contact Status 5	0=normal 1=active
BI65*	Output Contact Status 6	0=normal 1=active
BI66*	Output Contact Status 7	0=normal 1=active
BI67*	Output Contact Status 8	0=normal 1=active
FI1	AlarmLog	
FI3	TestLog	

<sup>\*</sup> Object\_Name is writable for these objects.

# **Protocol Implementation**

Vendor Name: Myers Power Products, Inc.

Product Name: EBI

Product Model Number: PCB404303P00

Applications Software Version: v2.00
Firmware Revision: v1.07
BACnet Protocol Revision: 12

#### **BACnet Standardized Device Profile (Annex L)**

EBI is capable of supporting the B-ASC profile and lower.

#### BACnet Interoperability Building Blocks Supported (Annex K)

DM-DDB-B, DM-DCC-B, DM-DOB-B, DM-TS-B, DM-RD-B, DS-RP-B, DS-WP-B

#### Segmentation Capability

EBI does not support segmentation.

## Standard Object Types Supported

No object types may be dynamically created or deleted.

OBJECT NAME

EBI supports the following object types:

Analog Input, Binary Input, Device and File.

Optional Properties Supported:

<b>D</b> 0 1.00	02020:_::::::::::::::::::::::::::::::::	***********	0_ 000
	OBJECT_IDENTIFIER	writable	
	DESCRIPTION	writable	64 chars
Binary Input	INACTIVE_TEXT	read-only	
	ACTIVE_TEXT	read-only	
DIEO DIGT		uwitahla	20 abara

writable

32 chars

BI52..BI67 OBJECT\_NAME writable 32 chars File ARCHIVE writable

## **Data Link Layer Options**

MS/TP master (Clause 9): 9600, 19200, 38400, 57600, and 115200 baud

## **Device Address Binding**

Static binding is not supported.

## **Networking Options**

EBI does not provide router or Annex H tunneling or BBMD functionality.

## **Character Sets Supported**

UTF-8

Device